

4-CELL BATTERY PACK TEMPLATE FOR 540r CONVERSION KIT



1. PRINT OUT ON PRINTER WITH A SCALE OF 1:1.
2. ASSEMBLE BATTERIES AS SHOWN.
 - a. 3 CELLS SIDE BY SIDE AND THE 4TH CELL AT A DISTANCE OF 8.30MM EDGE TO EDGE OR 30.65MM CENTER TO CENTER.
3. USE TWO BATTERY BARS TO CONNECT THE 3 CELLS.
4. USE TWO WIRES TO CONNECT THE PLUG AND A THIRD WIRE TO CONNECT THE 4TH CELL.
5. INSTALL INTO CAR AS SHOWN.

